

# LIGHT

LIG100..

LIG101..M

LIG103..M

LIG101..70


LIG103..70

LIG006..70

LIG007..70


LIG100..

LIG102..



# 1


## Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX



OK


**2**  
**a**



101..M  
103..M  
101..70  
103..70




**b**



101..M  
103..M


**c**



101..70  
103..70


**d**

101..M  
103..M




**e**


101..70  
103..70




# 3 a




# b




# c




# d




# 4 a



# b









# c




# M

## Manutenzione Service




**S**  
**a**

### Sostituzione Cartuccia How to replace Cartridge



101..M  
103..M  
101..70  
103..70


**b**



006..70  
007..70


**c**

### Sostituzione Vitone Ceramico How to replace Ceramic Disc Valve



**d**

### Sostituzione Aeratore How to replace Aerator



101..M 100..  
103..M 102..  
101..70  
103..70