

RED

RED 075..EWS

RED 071..EWS

RED 071..

RED 075..

RED 070..


RED 071..120

RED 131..

RED 135..

RED 130..

ZPRO125..



1


Montaggio Assembly



$65 \pm 5^{\circ}\text{C}$



$15 \pm 5^{\circ}\text{C}$




MIN - MAX



OK


2

a




075ES 071ES
071 070 075
071..120
131 130 135

b





c




075EWS
070 075
130 135

d

075ES 071ES
071 070 075
071..120
131 130 135



G 3/8"





Ø 33,5 MIN
36 MAX





40 MAX

075EWS
070 075
130 135

e





ZPRO125..
125 mm




F

Funzionamento
Working


075 EWS
071 EWS





M


Manutenzione Service






Sostituzione Cartuccia
How to replace Cartridge

075ES 071ES
071 070 075
081 080 085
131 130 135




075ES 071ES
071 070 075
081 080 085
131 130 135



Sostituzione Aeratore
How to replace Aerator

b



c

Sostituzione Snodo
How to replace Joint

131 130 135